















REMOTE CONTROL INSTRUCTIONS

	Frequency switching
	Turn on/off the microphone
	Size adjustment
	Reset the image size to default
	Adjust the image position
	Restore factory settings



	Far focus, AF/MF switch, Micro focus
	Enable/Disable the Image
	Adjust the screen orientation
	Adjust the default brightness of the image
	Adjust the image brightness

> How to pair YPW-QHDAF-M1 FlexCam with remote control?

The remote control may not work due to interference from surrounding electronic devices, in which case please try to re-pair the device.

Step 1. Before pairing remote, please connect the webcam to your computer and open the video software to ensure the webcam is in working status.

Step 2. Press and hold both buttons within the red circle as below simultaneously for a duration of 5 seconds. As a result, you should observe the message **"PAIRED"** appearing on your computer screen, indicating successful pairing.



> How do I unpair the devices?

Please press and hold the two buttons inside the blue circle in the image below simultaneously for 5 seconds. You will then see the message **"UNPAIRED"** on your computer screen, indicating that the pairing has been successfully canceled.

