


## USER MANUAL

MANUAL DE USUARIO



**MECHANICAL RED SWITCH**  
SWITCH ROJO MECÁNICO



**BLUETOOTH PAIRING**  
EMPAREJAMIENTO BLUETOOTH



**FULL N-KEY ROLLOVER**  
N-KEY ROLLOVER COMPLETO



**REMOVABLE BRAIDED TYPE C CABLE**  
CABLE TRENZADO DESMONTABLE TIPO C

## SPECIFICATIONS

<b>Number of Buttons</b>	68 Key Standard QWERTY Layout (ANSI)
<b>Feature</b>	Full N-Key Rollover
<b>Polling Rate</b>	1000 Hz
<b>Backlight</b>	16.8 Million Colors RGB LED
<b>Cable</b>	Removable Braided Type C Cable
<b>Cable Length</b>	5.9 ft
<b>Keycap</b>	ABS Double-Shot Injection Keycap
<b>USB Support</b>	USB 2.0
<b>Battery Capacity</b>	2000mA
<b>Usage Time</b>	8 Hours - 12 Hours (Backlight Mode On)
<b>Standby Mode</b>	8 Days
<b>Charging Time</b>	4 Hours
<b>Dimensions</b>	11.8 in x 5.6 in x 1.3 in ± 0.01 in
<b>Weight</b>	1.78lb ± 0.02lb
<b>Compatible OS</b>	Win 7 / 8 / 10

### FN Combination Keys and Special Function

**FN+WIN-L:** Lock & Unlock Win  
**FN+BACK SPACE:** Factory Restore  
**FN+A:** WIN System  
**FN+S:** IOS System

### Lighting Mode Control

**FN+DEL:** Static, Single-On, Single-Off, Rotate, Scroll, Roll, Fall, Colorful, Glitter

**FN+INS:** Ripples, Explode, Launch, Breath, Outward, Spectrum, Pulsate, Flow, Tilt

### Gaming Keys Control

**FN+Z:** FPS Game: W/A/S/D/↑/↓/←/→  
**FN+X:** Default LOL: Q/W/E/R/D/G/F/B/V/L-Ctrl/L-Alt/Tab/Space/1-6/Esc  
**FN+C:** Default 36Key Office Mode: A to Z / / \ / ; / ' / . / , / ! / ~ / ← / →

### To Record the Light Settings in GAME KEYS MODE

Press **FN+TAB** to Record / Store Lighting Mode, each pressing change a color when recording, total 8 colors.

### Lighting Control

**FN+PG UP:** Adjust the Light Brightness (+)  
**FN+PG DN:** Adjust the Light Brightness (-)  
**FN+↓:** Adjust the Speed of the LED (Slow)  
**FN+↑:** Adjust the Speed of the LED (Fast)  
**FN+←:** Adjust the Directions of the Dynamic LED  
**FN+→:** Adjust the Color of the Backlight

### Bluetooth Pairing

1. Set switch on the back of the keyboard to the 'ON' position
2. Press and hold **FN + P** for 3-5 seconds into Pairing Mode
3. The 'P' key will flash repeatedly to indicate that the keyboard is ready to connect to a new device over Bluetooth.

4. On the device you wish to connect to, search for Bluetooth devices and select 'Bluetooth Keyboard' to pair the device.
5. Once the keyboard has connected to the device, the 'P' key will stop flashing to indicate successful Bluetooth pairing.
6. The keyboard can support Bluetooth connections for up to three devices. Press and hold **FN+P** and **Q/W/E** to set up a connection to a new device.
7. Switch previously paired devices by quickly pressing **FM + Q/W/E**

### FN : Function Shift


**Default Function**  
ESC / 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9 / 0 / - / =  
Shift Function by pressing: **FN**  
~ / F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12



### Battery and Charging in BT mode

Red LED indicator will illuminate when battery is charging. Red LED indicator will shut off when battery is fully charged "FN" key backlight LED will flash repeatedly when battery is low  
Backlights will shut off after 5 minutes without use to conserve battery. After 30 minutes without use keyboard will enter standby mode and disconnect from Bluetooth. Press any key to exit standby mode and wake up the keyboard. Note the voltage at 5V current 1A when charging

### LED Indicators



- 1 Caps lock
- 2 Battery indicator

## ESPECIFICACIONES

<b>Número de Botones</b>	69 Teclas Estándar Diseño QWERTY (ANSI)
<b>Característica</b>	N-Key Rollover Completo
<b>Tasa de Sondeo</b>	1000 Hz
<b>Retroiluminado</b>	16.8 Millones de Colores RGB LED
<b>Cable</b>	Cable Trenzado Extraíble Tipo C
<b>Longitud del Cable</b>	1.8 M
<b>Tecla</b>	Tapas de inyección de doble capa ABS
<b>Soporte USB</b>	USB 2.0
<b>Capacidad de la Pila</b>	2000mA
<b>Tiempo de Uso</b>	8 Horas - 12 Horas (Modo Luz de Fondo Encendido)
<b>Modo de Espera</b>	8 Días
<b>Tiempo de Carga</b>	4 Horas
<b>Dimensiones</b>	302mm x 142.5mm x 34.8mm ± 0.3mm
<b>Peso</b>	810g ± 10g
<b>Sistema Operativo Compatible</b>	Win 7 / 8 / 10

### Teclas de Combinación FN y Función Especial

**FN+WIN-L:** Bloquear y Desbloquear Windows  
**FN+TECLA RETROCESO:** Restauración de Fábrica  
**FN+A:** Sistema Windows  
**FN+S:** Sistema IOS

### Control de Modo de Iluminación

**FN+DEL:** Estático, Encendido Simple, Apagado Simple, Rotar, Desplazarse, Rodar, Caer, Colorido, Brillo  
**FN+INS:** Ondas, Explotar, Lanzar, Respirar, Exterior, Espectro, Pulsar, Fluir, Inclinar

### Control Teclas de Juego

**FN+Z:** Juego FPS: W/A/S/D/↑/↓/←/→  
**FN+X:** LOL Predeterminado: Q/W/E/R/D/G/F/B/V/L-Ctrl/L-Alt/Tab/Espacio/1-6/Esc  
**FN+C:** Predeterminado 36Teclas Modo Oficina: A a Z / / \ / ; / ' / . / , / ! / ~ / ← / →

### Para grabar la configuración de luces en TECLAS DE JUEGO

Presione **FN + TAB** para grabar / almacenar el modo de iluminación, cada presión cambia un color al grabar dando un total de 8 colores.

### Control de Iluminación

**FN+PG UP:** Ajuste el Brillo de la Luz (+)  
**FN+PG DN:** Ajuste el Brillo de la Luz (-)  
**FN+↓:** Ajuste la Velocidad del LED (Lento)  
**FN+↑:** Ajuste la Velocidad del LED (Rápido)  
**FN+←:** Ajuste las Direcciones del LED dinámico  
**FN+→:** Ajusta el Color de la Luz de Fondo

### Emparejamiento Bluetooth

1. Ponga el interruptor en la parte posterior del teclado en la posición 'ON'
2. Mantenga presionado **FN + P** durante 3-5 segundos en el modo de emparejamiento.
3. La tecla 'P' parpadeará repetidamente para indicar que el teclado está listo para conectarse a un nuevo dispositivo a través de Bluetooth.
4. En el dispositivo al que desea conectarse, busque dispositivos Bluetooth y seleccione 'Teclado Bluetooth' para emparejar el dispositivo.

5. Una vez que el teclado se haya conectado al dispositivo, la tecla 'P' dejará de parpadear para indicar que el emparejamiento de Bluetooth se realizó correctamente.
6. El teclado puede admitir conexiones Bluetooth para hasta tres dispositivos. Mantenga presionados **FN + P y Q / W / E** para configurar una conexión a un nuevo dispositivo.
7. Cambie los dispositivos previamente emparejados presionando rápidamente **FM + Q / W / E**

### FN: Cambio de Función

**Función Predeterminado**  
ESC / 1 / 2 / 3 / 4 / 5 / 6 / 7 / 8 / 9 / 0 / ' / i  
Cambia de Función al presionar: **FN**  
~ / F1 / F2 / F3 / F4 / F5 / F6 / F7 / F8 / F9 / F10 / F11 / F12



### Carga de la batería en modo BT

El indicador LED rojo se iluminará cuando la batería se esté cargando.  
El indicador LED ROJO se apagará cuando la batería esté completamente cargada  
El LED de luz de fondo de la tecla "FN" parpadeará repetidamente cuando la batería esté baja  
Las luces de fondo se apagarán después de 5 minutos sin usarse para ahorrar batería. Después de 30 minutos sin usar, el teclado entrará en modo de espera y se desconectará de Bluetooth. Presione cualquier tecla para salir del modo de espera y activar el teclado. Tenga en cuenta el voltaje a 5 V de corriente 1A al cargar

### Indicadores LED



- 1 Bloqueo de mayúsculas
- 2 Indicador de batería